

- 1) Remove all attaching parts from the Fill up 2 driving module, e.g. power cable, stand and gear pump module
- 2) Unscrew and remove all 6 screws at the top of the housing and the 6 screws at the housing base (see arrows) with a suitable Allen key.



- 3) The front and back part of the housing must be pulled apart only a few centimetres until the defective clamping lever can be removed
- 4) Insert the new clamping lever at the same position
- 5) Push together both parts of the housing and screw in again the 12 screws.



PRODUKTSERVICE STEFAN WEILAND
LEIPZIGER STR. 33
01097 DRESDEN
GERMANY



WEB www.nassenheider.com

TELEPHONE + FAX

Office +49 (0)351 - 89 66 91-00
Sale +49 (0)351 - 89 66 91-01
Support +49 (0)351 - 89 66 91-05
Fax +49 (0)351 - 89 66 91-99

E-MAIL info@nassenheider.com